

ENABLE FN KEYS IN LAPTOPS LIKE



Enable or Disable fn (Function) or Action Keys Mode

► Change the action key setting from the BIOS Setup Utility.

1. Press and hold the **power** button for at least five seconds to turn off the computer.
2. Turn on the computer and immediately press the **f10** key repeatedly to open the BIOS Setup Utility.
3. Press the right or left arrow key to select the **System Configuration** menu.
4. Press the up or down arrow key to select **Action Keys Mode**.
5. Press the **enter** key to display the Enabled / Disabled options.



6. Press the up or down arrow key to select one of the options.

- **Enabled:** Does not require pressing **fn** to use the actions printed on the function keys.

For example, pressing **f8** lowers the sound as printed on the key. Alternately, pressing both the **fn + f8** keys minimizes and maximizes a web browser.

- **Disabled:** Requires pressing **fn** to use the actions printed on the function keys.

For example, pressing **f1** opens a help window. Alternately, pressing both the **fn + f1** keys puts the computer in Sleep mode as printed on the key.

7. Press the **f10** key to save the selection and restart the computer.



Lenovo



ASUS

Manufacturers	Fn Lock Key Combination
Dell/Lenovo	Fn + Esc
HP	Fn + Shift or Ctrl+Fn
Asus	Fn + Esc or Fn + Insert or Fn + Shift